

HB20

L intermedio



	Ø
HB200300	3
HB200400	4
HB200500	5
HB200600	6
HB200800	8
HB201000	10
HB201200	12
HB201400	14

HB21

T intermedio



	Ø1	Ø2
HB210300	3	3
HB210400	4	4
HB210500	5	5
HB210600	6	6
HB210604	6	4
HB210800	8	8
HB210806	8	6
HB211000	10	10
HB211008	10	8
HB211200	12	12
HB211400	14	14

HB24

Riduzione



Ø1		Ø1	Ø2	Ø1	Ø2	
	HB240405	4	5	HB240612	6	12
	HB240406	4	6	HB240614	6	14
	HB240408	4	8	HB240806	8	6
	HB240412	4	12	HB240810	8	10
	HB240414	4	14	HB240812	8	12
	HB240506	5	6	HB240814	8	14
	HB240508	5	8	HB241012	10	12
	HB240604	6	4	HB241014	10	14
	HB240608	6	8	HB241214	12	14
	HB240610	6	10			

HB26

Tappo



	Ø
HB260400	4
HB260500	5
HB260600	6
HB260800	8
HB261000	10
HB261200	12
HB261400	14

HB27

Gomito girevole cilindrico testa chiave incassata

	Ø	attacco		Ø	attacco
HB2703M3	3	M3	HB270614	6	G1/4
HB2703M5	3	M5	HB270814	8	G1/4
HB2704M5	4	M5	HB271014	10	G1/4
HB2705M5	5	M5	HB271214	12	G1/4
HB270418	4	G1/8	HB270838	8	G3/8
HB270518	5	G1/8	HB271038	10	G3/8
HB270618	6	G1/8	HB271238	12	G3/8
HB270818	8	G1/8			

HB33

Passaparete



	Ø
HB330004	4
HB330005	5
HB330006	6
HB330008	8
HB330010	10
HB330012	12
HB330014	14

HB34

Passaparete connessione filettata



	Ø	attacco
HB340418	4	G1/8
HB340618	6	G1/8
HB340818	8	G1/8
HB340614	6	G1/4
HB340814	8	G1/4

HB35

Passaparete raccordo a gomito



	Ø
HB350004	4
HB350006	6
HB350008	8
HB350010	10

HB38

Gomito innestabile



	Ø1	Ø2
HB380400	4	4
HB380406	4	6
HB380600	6	6
HB380608	6	8
HB380800	8	8
HB381000	10	10
HB381200	12	12

HB39

Gomito innestabile alto



	Ø1	Ø2
HB390400	4	4
HB390406	4	6
HB390600	6	6
HB390608	6	8
HB390800	8	8