











Ø	 	GOMITO 90° UGUALE					
		Transair®	ØD	ØG	L	Z	Kg
16,5		6602 17 00	16,5	34	58	31	0,065
25		6602 25 00	25	44,5	69,5	40	0,120
40		6602 40 00	40	67	103	62	0,410



Ø	 	GOMITO 90° UGUALE					
		Transair®	ØD	ØG	L	Z	Kg
50		6602 50 00	50	80	116	56	0,804
63		6602 63 00	63	91	124	61	0,970

Ø	 	GOMITO 90° UGUALE				
		Transair®	ØD	H	Z	Kg
76		RX02 L1 00	76	227	189	1,033
100		RX02 L3 00	100	278	227	1,417
168		RA02 L8 00	168	269	185	3,074

I gomiti a 90° RX02 e RA02 si collegano al tubo Transair® per mezzo di due connettori RR01.

Ø	 	GOMITO 45° UGUALE					
		Transair®	ØD	ØG	L	Z	Kg
25		6612 25 00	25	44,5	61,5	32,5	0,115
40		6612 40 00	40	67	90	45	0,370

Ø	 	GOMITO 45° UGUALE					
		Transair®	ØD	ØG	L	Z	Kg
50		6612 50 00	50	80	98	38	0,771
63		6612 63 00	63	91	100	37	0,906

Ø	 	GOMITO 45° UGUALE				
		Transair®	ØD	L1	Z	Kg
76		RX12 L1 00	76	235,5	122	0,704
100		RX12 L3 00	100	271,4	138	1,309
168		RA12 L8 00	168	310,5	147,5	2,366

I gomiti a 45° RX12 e RA12 si collegano al tubo Transair® per mezzo di due connettori RR01.